

# EcoPrimer Manual

---

EcoPrimer is a ready-to-use primer that ensures good adhesion and bonding.

## Preparation

EcoPrimer is suitable for various substrates. It can be used on plastered walls, glass fibre wallpaper, spachtelputz, MDF, etc... When in doubt whether EcoPrimer/paint is suitable for your wall, contact our customer service for advice.

## Applying EcoPrimer

Step 1: check the temperature. EcoPrimer is best applied at temperatures between 7 °C and 27 °C.

Step 2: mix the EcoPrimer well with a stirrer or whisk.

Step 3: apply EcoPrimer to a grease-free, dust-free, clean and dry surface. This is best done with a microfibre roller. Apply the primer in a thin layer.

Step 4: let the primer dry for at least 12 hours.

Step 5: always apply a second coat of EcoPrimer on an absorbent surface.

---

## Shelf life

EcoPrimer has an unopened shelf life of 12 months when stored in a dry environment, at a temperature between 10 °C and 30 °C.

## Practical tips

- When you're applying the primer on a shiny surface, sand lightly to ensure better adhesion.
- Always apply two coats on absorbent surfaces.
- For the best result: wait until the primer is thoroughly dry before you start painting.
- Thin the primer by up to 20% if it is too thick.